

Supporti per ventose - Serie BF
Fittings for suction cups - BF Series

Art =	Ventosa <i>Suction cup</i>	+ Supporto <i>+ Fitting</i>	+ Anello di rinforzo <i>Reinforcement ring</i>
BF 20 00	BF 20 35	SUF 30 00	SUF 30 19
BF 20 20	BF 20 35	SUF 30 18	SUF 30 19
BF 20 30	BF 20 35	SUF 30 10	-
BF 20 60	BF 20 35	SUF 30 60	SUF 30 19
BF 20 61	BF 20 35	SUF 30 61	SUF 30 19
BF 20 63	BF 20 35	SUF 30 63	SUF 30 19
BF 20 64	BF 20 35	SUF 30 64	SUF 30 19
BF 20 90	BF 20 35	SUF 30 90	SUF 30 19
BF 20 91	BF 20 35	SUF 30 91	SUF 30 19
BF 20 93	BF 20 35	SUF 30 93	SUF 30 19
BF 30 00	BF 30 35	SUF 30 00	SUF 30 19
BF 30 20	BF 30 35	SUF 30 18	SUF 30 19
BF 30 30	BF 30 35	SUF 30 10	-
BF 30 60	BF 30 35	SUF 30 60	SUF 30 19
BF 30 61	BF 30 35	SUF 30 61	SUF 30 19
BF 30 63	BF 30 35	SUF 30 63	SUF 30 19
BF 30 64	BF 30 35	SUF 30 64	SUF 30 19
BF 30 90	BF 30 35	SUF 30 90	SUF 30 19
BF 30 91	BF 30 35	SUF 30 91	SUF 30 19
BF 30 93	BF 30 35	SUF 30 93	SUF 30 19
BF 40 00	BF 40 35	SUF 40 00	SUF 40 19
BF 40 20	BF 40 35	SUF 40 18	SUF 40 19
BF 40 30	BF 40 35	SUF 40 10	-
BF 40 70	BF 40 35	SUF 40 70	SUF 40 19
BF 40 71	BF 40 35	SUF 40 71	SUF 40 19
BF 40 73	BF 40 35	SUF 40 73	SUF 40 19
BF 40 74	BF 40 35	SUF 40 74	SUF 40 19
BF 40 80	BF 40 35	SUF 40 80	SUF 40 19
BF 40 81	BF 40 35	SUF 40 81	SUF 40 19
BF 40 83	BF 40 35	SUF 40 83	SUF 40 19
BF 40 84	BF 40 35	SUF 40 84	SUF 40 19
BF 40 90	BF 40 35	SUF 40 90	SUF 40 19
BF 40 91	BF 40 35	SUF 40 91	SUF 40 19
BF 40 93	BF 40 35	SUF 40 93	SUF 40 19
BF 50 00	BF 50 35	SUF 50 00	SUF 50 19
BF 50 20	BF 50 35	SUF 50 18	SUF 50 19
BF 50 30	BF 50 35	SUF 50 10	-
BF 50 70	BF 50 35	SUF 50 70	SUF 50 19
BF 50 71	BF 50 35	SUF 50 71	SUF 50 19
BF 50 73	BF 50 35	SUF 50 73	SUF 50 19
BF 50 74	BF 50 35	SUF 50 74	SUF 50 19
BF 50 80	BF 50 35	SUF 50 80	SUF 50 19
BF 50 81	BF 50 35	SUF 50 81	SUF 50 19
BF 50 83	BF 50 35	SUF 50 83	SUF 50 19
BF 50 84	BF 50 35	SUF 50 84	SUF 50 19
BF 50 90	BF 50 35	SUF 50 90	SUF 50 19
BF 50 91	BF 50 35	SUF 50 91	SUF 50 19
BF 50 93	BF 50 35	SUF 50 93	SUF 50 19

Art =	Ventosa <i>Suction cup</i>	+ Supporto <i>+ Fitting</i>	+ Anello di rinforzo <i>Reinforcement ring</i>
BF 63 32	BF 63 35	SUF 63 32	-
BF 63 33	BF 63 35	SUF 63 33	-
BF 75 30	BF 75 35	SUF 75 10	-
BF 75 32	BF 75 35	SUF 75 32	-
BF 75 33	BF 75 35	SUF 75 33	-
BF 78 30	BF 78 35	SUF 75 10	-
BF 78 31	BF 78 35	SUF 75 10	-
Disco interno / Internal disc: SUF 75 06			
BF 78 32	BF 78 35	SUF 75 32	-
BF 78 33	BF 78 35	SUF 75 33	-
BF 78 321	BF 78 35	SUF 75 32	-
Disco interno / Internal disc: SUF 75 06			
BF 78 331	BF 78 35	SUF 75 33	-
Disco interno / Internal disc: SUF 75 06			
BF 110 30	BF 110 35	SUF 110 10	-
BF 110 32	BF 110 35	SUF 110 32	-
BF 110 33	BF 110 35	SUF 110 33	-
BF 115 30	BF 115 35	SUF 110 10	-
BF 115 31	BF 115 35	SUF 110 10	-
Disco interno / Internal disc: SUF 115 06			
BF 115 32	BF 115 35	SUF 110 32	-
BF 115 33	BF 115 35	SUF 110 33	-
BF 115 321	BF 115 35	SUF 110 32	-
Disco interno / Internal disc: SUF 115 06			
BF 115 331	BF 115 35	SUF 110 33	-
Disco interno / Internal disc: SUF 115 06			
BF 150 30	BF 150 35	SUF 150 10	-
BF 150 32	BF 150 35	SUF 150 32	-
BF 150 33	BF 150 35	SUF 150 33	-
BF 160 30	BF 160 35	SUF 150 10	-
BF 160 31	BF 160 35	SUF 150 10	-
Disco interno / Internal disc: SUF 160 06			
BF 160 32	BF 160 35	SUF 150 32	-
BF 160 33	BF 160 35	SUF 150 33	-
BF 160 321	BF 160 35	SUF 150 32	-
Disco interno / Internal disc: SUF 160 06			
BF 160 331	BF 160 35	SUF 150 33	-
Disco interno / Internal disc: SUF 160 06			